
For Home Wall Cabinet 2 Doors

Assembly Guide




Model: 3500001549 / 3500001557 / 3500001558





In order to ease the assembly, you should separate and identify the parts first



Do not place the parts directly onto the floor. Use a cardboard sheet or a mat to place the parts, during the separation and assembly.




Tools Needed (not supplied)



IDENTIFICATION OF PARTS


	IDENTIFY THE COLOR OF YOUR CABINET				DIMENSION					
N°	DESCRIPTION	BLACK MATTE	WHITE MATTE	GREY	MATERIAL	QUA	NTITY	LENGTH	WIDTH	THICKNESS
P1	SIDE	3000010597	3000010479	-	STEEL	2	PC	30,00"	12,50"	1,38"
P2	CEILING	3000010596	3000010478	-	STEEL	1	PC	30,26"	12,45"	1,38"
P3	REAR	3000010595	3000010477	-	STEEL	1	PC	30,26"	12,45"	1,38"
P4	TOP BACK	3000010593	3000010475	-	STEEL	1	PC	27,5"	13,55"	0,57"
P5	ВОТТОМ ВАСК	3000010592	3000010469	-	STEEL	1	PC	27,5"	13,57"	0,54"
P6	WALL FIXATION SUPPORT	3000010668	3000010667	-	STEEL	1	PC	26,54"	1,77"	0,46"
P7	SHELF	3000010594	3000010476	-	STEEL	1	PC	30,22"	10,91"	1,14"
P8	RIGHT DOOR	3000010600	-	3000010465	STEEL	1	PC	26,81"	13,55"	0,65"
P9	LEFT DOOR	3000010601	-	3000010464	STEEL	1	PC	26,81"	13,85"	0,65"








Warning - Maximum distributed weight supported.



Assembled product:

H:30" W:30.3" L:12.5"

Hardware list






Locking nut, no key tightening required.


- **STEP 1** 1 Fit the **REAR** inside the **SIDE** part.
 - 2 Align the two holes in the corner and screw **F1** and **F2** to it.








- 1 Fit the **CEILING** inside the **SIDE** part.
- 2 Align the two holes in the corner and screw **F1** and **F2** to it.





- 1 Fit the **CEILING** and **REAR** inside the **SIDE**.
- 2 Fit the **SIDE** part to the corners of the **CEILING** and **REAR** parts. Align the holes and screw **F1** and **F2** to it.






 Turn the cabinet with the back side upwards.




Important


Check if all parts are correctly supported to ensure the product alignment.



2 - Align the holes and screw **F1** and **F2** to it.




- 1 Fit the **TOP BACK** into the **CEILING** and the **SIDE** parts.
 - 2 Check if all parts are supported over the bolts holes.
 - 3 After fitting the parts, screw the bolts until locked.



STEP 6

1 - With the end of **F13**, smash the safety claw, locking the **TOP BLACK** to the **SIDE**.









To avoid possible problems, the safety claw must be locked.

- **STEP 7** 1 Fit the **BOTTOM BACK** inside the **SIDE**, **CEILING** and **REAR**. Check if all parts are supported over the bolts holes.
 - 2 After fitting the parts, screw the bolts until locked.




- 1 Turn the cabinet to the position of use as shown in the picture.
- 2 Fix the four **F7** parts to both **SIDES** as shown below.






- **STEP 9** 1 Place the **SHELF** diagonally so it fits inside the cupboard.
 - 2 Lean the SHELF and place it over the F7 fixed on the SIDE as detailed in the illustration below.
 - 3 Place the other side of the **SHELF** down.











- 1 Align the **WALL FIXATION SUPPORT** at an approximate 72 ½" height from the floor.
 - 2 Align the part using a level.
 - 3 Mark the wall using the holes of the WALL FIXATION SUPPORT with a pencil.
 - 4 On the market spots, drill the wall using a Driller with a 1 ½" (13 mm) drill.



Important - The Cabinet must be fixed on the wall.


WALL FIXATION SUPPORT









1 - Insert the metal part of the bushing into the hole until it overcomes the wall.







2 - Pull the bushing and drive it against the wall and then push the plastic ring until it leans close to the wall.




3 - Break the bushing's rods







STEP 12 1 - Align the WALL FIXATION SUPPORT part to the bushings holes and screws the F5 to the wall...




2 - Fix the Cabinet to the WALL FIXATION SUPPORT to be hold on the wall. The Tab of TOP BACK part must be used to this purpose.





- 1 To assembly the doors, fit the **LEFT DOOR** lower hinge bolt inside the hole in the **REAR** part.
- 2 Then, pull the pin of **LEFT DOOR** upper hinge down; align the door and release the pin to fit the hole in the **CEILING**.
- 3 Repeat the step for the **RIGHT DOOR**.





WARRANTS TERMS AND CONDITIONS ITRE PRODUCTS



This document describes the limited warranty agreement ('Warranty') regarding your purchase of ITBE's furniture and/or equipment ('Product') within USA territory. This agreement is subject to the conditions described below.

1.WARRANTY SCOPE

- 1.1. This Warranty covers Product defects resulting from defective parts, materials or manufacturing, if such defects occur during the period of 12 months after the date of purchase.
- 1.2. The Products are considered defective if they fails to perform the functions as indicated in the operation manuals, technical specifications or any other similar documents supplied with the Products, and the failure is due to material and workmanship defects.
- 1.3. During the Warranty period, if a defect arises in the Product, ITBE will, at his option and to the extent permitted by law, either (i) repair the Products using either new or refurbished parts, (ii) replace the Product with a new or refurbished Product that is equivalent or similar to the Product to be replaced, or (iii) refund to Buyer all or part of the purchase price of the Product.

2.WARRANTY LIMITATIONS

2.1. This Warranty does not cover:

- i. In-home service including, but not limited to, service calls to correct the installation of any Products or to instruct Buver on how to use or install them.
 - ii. Damage or failure resulting from modification, alteration, misuse or abuse of a Product.
 - **iii.** Damage caused by a carrier or third party, including resulting from improper handling or shipping of Products, or Products damaged by accident, alteration, misuse, abuse, fire, flood, improper installation, acts of God, neglect, corrosion, modification or mishandling.
 - iv. Factory specified replacement parts or Product replacement when Buyer's Product is used in other than normal, single-family household use, such as a commercial environment or handled in a manner contrary to published user or operator instructions and/or installation instructions.
 - v. Aesthetic damages including scratches, dings, dents or cracks that do not affect the structural or functional capability of the Product.
 - vi. Damage resulting from improper loading beyond the specified maximum weight capacity outlined in the assembly instructions provided with the Product including overloading of hooks, baskets, shelves, cabinets, and other accessories used with the Product.
- vi. Surfaces damaged due to chemical interaction resulting in corrosion of paint, metal or any treatment or cleaning product that is not recommended by ITBE.
- vii. Color and other covering materials.
- ix. Drawers and doors, as they may run tight or lose due to high variation in humidity and temperature in the surrounding atmosphere.
- x. Replacement keys or locking mechanism.
- xi. Natural wear and tear of the Product.
- xii. Any labor costs during the Warranty period.
- 2.2 ITBE must be notified of any defect and given an opportunity to remedy it; any remedial work carried out by a third party will nullify this warranty.
- 2.3 The cost of repair or replacement under these excluded circumstances shall be borne by Buyer.



3. PROCEDURE AND EVALUATION



- 3.1 If Buyer has received a defective Product, Buyer must report the defect by sending an e-mail to To be able to help@itbehome.com make a warranty claim, Buyer must always present proof of purchase send a photo of the defective Product and provide a detailed description of the defect.
- 3.2 Buyer will receive a confirmatory email with a number code and ITBE will process the report within 2 business days. If the photo sent by Buyer is not enough to determine the cause of the Product defect, ITBE may request further explanation, carry out an on-site examination of the Product or require Buyer to send the Product to the nearest support center. If an on-site examination is necessary, Buyer must grant free direct access to ITBE's technician as needed.
- 3.3 If there is any doubt about whether the problem with the defective Products falls under the Warranty, the burden of proof of the existence of material and workmanship defects lies with Buyer.
- **3.4** Warranty services will be provided only if a material or workmanship defect is demonstrated, and the defect does not fall under clause 2.
- **3.5** After evaluation, ITBE will, on its discretion, either repair or replace the defective parts of the Product or the Product itself or refund the purchase price to Buyer. ITBE shall provide Buyer with a forecast of the time required for the repair or replacement of the Product.
- 3.6 If a product or its part has to be replaced and that particular product or part is no longer available, ITBE reserves the right to use an alternative similar product or part.
- 3.7 When a warranty claim is justified, ITBE will pay for shipping expenses for repairing or replacing the Product. ITBE can charge Buyer for returned Products that are not found to be defective or non-conforming, in addition to shipping-test, and handling costs associated therewith.
- 3.8 The warranty does not cover any costs associated with installation, removal or reinstallation of a Product, when applicable.

4.WARRANTIES AND DAMAGES

- **4.1** To the extent permitted by law, the Warranty and remedies set forth above are exclusive and in lieu of all other warranties and remedies. ITBE specifically disclaims all statutory or implied warranties, including, but not limited to, warranties of merchantability, fitness for a particular purpose and against hidden or latent defects.
- 4.2 ITBE DOES NOT PROVIDE, AND SPECIFICALLY DISCLAIMS, ANY OTHER WARRANTIES FOR THE PRODUCTS, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ITBE SHALL NOT BE LIABLE FOR OR OBLIGATED IN ANY WAY TO PAY CONSEQUENTIAL OR INDIRECT DAMAGES, INCLUDING, WITHOUT LIMITATION, LOSS OF PROFITS, FINES OR LEGAL ACTIONS BY THIRD PARTIES. IN ANY EVENT, ITBE'S LIABILITY AS RELATED TO THE SUPPLY OF THE PRODUCT SHALL NOT EXCEED THE AMOUNT EFFECTIVELY PAID BY THE BUYER.
- 4.3 ITBE is not obliged to notify any Buyer, or future Buyer, after a certain date about any possible amendments or the non-applicability of this limited warranty regarding the supplied Products. The Warranty as described below is subject to the limits and other conditions described herein.





Keep this booklet and your proof of purchase together for future reference. You will need to provide proof of purchase to obtain service under warranty.

Write the following information regarding your Product to help you get Better assistance or service should you ever need it.

You should have the complete model number. You can find this information on the label that is located in the package. as an example below:

1234564510000 COPY THIS NUMBER

ITBE	7			
0001/0003	00000000	PARRICACION OO/OO/OO	1 2 3 4 5 6 4 5 1 0 0 0 0	
PD 1P-35 ITB	E EASY FIT BRI	M/BRM	PACKED SIZE: GROSS WEIGTH: VOL/UNIT:	
	Assembed Product 13.77" X 25.19" X 11.22" IN			

Distributor name
Address
Phone number
Model number
Serial number
Date of purchase



Taking good care of your cabinet



Important - In order to avoid severe or even fatal injuries, follow the instructions carefully.



Need Help?



Any questions on the assembly?
Contact us.

help@itbehome.com

